


# SOMMERKAMP<sup>®</sup>

## MODEL TS 624S

24 - CHANNEL 10 - WATT  
MOBILE TRANSCEIVER



## INSTRUCTION MANUAL

### SOKA SRL

CH-6911 CAMPIONE / LUGANO  
VIA MATTEO 17 SWITZERLAND

## INSTALLATION


Mounting bracket and screws are supplied for mounting the transceiver underneath the dashboard. Microphone hanger and screws are also supplied.

For electrical connection, first make sure that the transceiver is turned off. Connect the red wire to the ACC terminal of the ignition switch or + terminal of battery and ground the black wire to the chassis of the vehicle. The black wire should be grounded as short as possible to minimize the noise interference.

This transceiver is designed for use with the **negative** ground system.  
(For installation in the positive ground system, see the following instructions.)

Installation in positive ground system:

- a) Since the cabinet is commonly connected to all B minus potentials in the transceiver, the transceiver must be electrically isolated from the chassis of the vehicle at all times. (See Fig. 1 for connection with power source.)



TRCV CHASSIS TO BE  
INSULATED FROM CAR

FIG. 1

- b) Obtain a pair of 0.01 mfd. @500V ceramic capacitors. Cut the antenna coaxial cable approximately 3 inches from the male connector. Connect one of the 0.01 capacitors in line with the center copper wire of the coaxial cable and solder. Tape the connections. Add the other capacitor in line with the shielding braids and solder. Tape the entire exposed braids and capacitor for insulation. These capacitors, in line with the conductors of the coaxial cable, now isolate the antenna ground from the ground of the transceiver. (See Fig. 2)





FIG. 2

c) The mounting bracket must be isolated from the chassis of the vehicle in such a manner as shown in Fig. 3.



## ANTENNA

Antenna is one of the most important factors to the operation with maximum efficiency. A quarter wave antenna can be successfully mounted for mobile station. The antenna impedance should be 50 ohms. For the details, consult with your distributor.

### Important:

Do not operate the transceiver without a proper antenna or dummy load connected to the antenna connector, as the transmitter transistors may be damaged.

## OPERATING INSTRUCTIONS

The transceiver is ready to operate when it is installed with an antenna properly connected. Note that the communication range differs depending upon the environment where the transceiver is operated. You may reach 30 or 40 kilometers where no obstacle exists, but the range may be limited to 5 or 6 kilometers in cities where many high buildings disturbs the communication.

- 1) Turn the set on by pushing the volume control knob and the channel dial will be lighted. Turn the volume control clockwise to increase the audio sound. Note that the volume control knob is only for adjusting the audio volume, not to increase the transmitting power.
- 2) Turn the squelch control clockwise until incoming noise is eliminated. Do not turn it excessively, as the sensitivity may be reduced.
- 3) Turn the channel selector knob for the desired channel.
- 4) For transmitting, press the button on the microphone and speak into it normally. Release the button for receiving.

## METER

The meter reading indicates the signal strength at receiving, and functions as an output indicator at transmitting, and the meter pointer should be within the blue zone under the normal conditions.

## STONE-LIGHT CALLING DEVICE

The Model TS 624S is equipped with a selective tone-light calling device which works on 1,080 Hz signal. To call the other station, push the push-to-talk button and the call button simultaneously, when the calling signal is transmitted. When the signal is received, a beep tone is produced and the call-light lamp will be lighted at the other station, and the lamp stays on until the other station answers. Please note that the device works only when the other station is switched on and that the buttons on the calling side must be depressed at least for 10 seconds.

List of accessories:

Mounting bracket .....	1
Self-tapping screw for above .....	4
Washer for above .....	4
Hexagonal screw .....	4
Microphone hanger .....	1
Screw for above .....	2
Plug for external speaker .....	1

List of channel frequencies:

CHANNEL NO.	FREQUENCY	CHANNEL NO.	FREQUENCY
1	26.965 Mhz	13	27.115 Mhz
2	26.975 Mhz	14	27.125 Mhz
3	26.985 Mhz	15	27.135 Mhz
4	27.005 Mhz	16	27.155 Mhz
5	27.015 Mhz	17	27.165 Mhz
6	27.025 Mhz	18	27.175 Mhz
7	27.035 Mhz	19	27.185 Mhz
8	27.055 Mhz	20	27.205 Mhz
9	27.065 Mhz	21	27.215 Mhz
10	27.075 Mhz	22	27.225 Mhz
11	27.085 Mhz	23	27.255 Mhz
12	27.105 Mhz	24	27.275 Mhz

S3 POWER SW. & R1 VOLUME

R2 SQUELCH

Q11 2SC838H or CS2001G

L10 RF COIL

L12 RF COIL

R4 CALL MOD. ADJ.

D12 2SF656

C35 0.1 $\mu$ F

Q13 2SC838H or CS2001G

L8 AF COIL

R3 CALL SENS. ADJ.

Q6 2SC945R or CS2001G

Q8 2SC945Q or CS2001I

Q9 2SD142M

L7 3rd IFT

Q7 2SC945Q or CS2001I

Q10 2SD142M

T1 DRIV. TRANS.

Q5 2SC838H or CS2001G

L25 NOISE CHOKE

L6 2nd IFT

Q4 2SC838F or CS2001H

T2 OUTPUT TRANS.

CF CERAMIC FILTER

L5 1st IFT

J1 EXT. SP. JACK

K1 RELAY

PL1 CALL LAMP

S1 CHANNEL SELECTOR

M RF-S METER

L13 RF COIL

L14 RF COIL

Q14 2SC838F or CS2001H

Q15 2SC815

Q18 2SC945Q or CS2001I

L15 RF COIL

Q19 2SC838Q or CS2001I

Q20 2SC945R or CS2001G

Q16 2SC781

L16 RF COIL

L11 RF COIL

CRYSTAL SOCKET

Q17 2SC1306

L3 RF COIL

Q2 2SC839F or CS2001H

L4 RF COIL

L21 RF COIL

L2 RF COIL

Q1 2SC922 or CS2008F


L1 RF COIL



L22 RF COIL

Q3 2SC838F or CS2001H


Q12 2SC838H or CS2001G

J2 ANTENNA JACK





# TS 624S SCHEMATIC DIAGRAM



**NOTES:**

1. ALL RESISTANCE VALUES ARE IN OHMS UNLESS OTHERWISE SPECIFIED.
2. ALL RESISTANCE ARE 1/2 WATTS UNLESS OTHERWISE SPECIFIED.
3. ALL CAPACITANCE VALUES EXPRESSED AS WHOLE NUMBERS ARE IN MICROMICROFARADS UNLESS OTHERWISE SPECIFIED.
4. SIGNAL LEVEL MEASUREMENT CONDITIONS FOR 1/2 WATTS AUDIO OUTPUT.
5. CHANNEL SELECTOR SI SHOWN IN CHANNEL 1 POSITION.

**6. FREQUENCY SYNTHESIZER CRYSTAL FREQUENCIES ARE AS FOLLOWS:**

Y1	37,600 MHz	Y7	10,180	Y11	10,635
Y2	37,650	Y8	10,170	Y12	10,625
Y3	37,700	Y9	10,160	Y13	10,615
Y4	37,750	Y10	10,140	Y14	10,595
Y5	37,800				
Y6	37,850			Y15	37,890